





Manuál pro ovládání osvětlení OP2



Ovladač:

1-3 kapacitní tlačítka ve skle



DETAILNÍ POPIS OVLÁDÁNÍ (verze 1.01a/f7)


Osvětlení zrcadla se zapíná tlačítkem . Pokud je osvětlení zapnuté, lze dlouhým stiskem tlačítka  regulovat intenzitu osvětlení. V okamžiku, kdy světlo zabliká, dosáhli jste maximální hodnoty. Následně je možné dlouhým stiskem tlačítka  nastavit požadovanou barvu světla. V okamžiku, kdy světlo zabliká, dosáhli jste maximální hodnoty.

Pokud je instalována topná fólie (OP6), je možné stiskem tlačítka  zapnout nebo vypnout topnou fólii. Topnou fólii je možné vypnout spolu s osvětlením stiskem tlačítka .






Operating Manual for Option OP2

Controller:

1-3 independent touch switches



DETAILS (version 1.01a/f7)

The mirror lighting is switched on by the button . If lighting is on, the light can be controlled by pressing the button  for a long time. As soon as the light flashes, you have reached the maximal value. Then it is possible to set demanded light color by pressing the button  for a long time. As soon as the light flashes, you have reached the maximal value. If the heating pad is installed (OP6), it is possible to switch on, switch off it by pressing the button . The heating pad can be switch off together with the lighting by pressing the button .